

Water in Fuel Detection Kit

Hydrokit® HK Series “Go...no go” field water detect kit for Aviation Fuel



DESCRIPTION

The HYDROKIT® is an effective “Go, No-Go” field test designed to periodically check for free water, which is removed to ppm levels by properly operating filter/ separators, Aquacon®, and monitor vessels. Samples are normally taken downstream of the vessel, but they can also be taken at other points in the fuel distribution system.

The HYDROKIT® is designed to indicate free water in excess of 30* ppm by changing the powder contained in the sample tube to a pink color. Thirty ppm is generally accepted as the maximum amount of water permissible when fueling aircraft. The HYDROKIT® is designed for “fail-safe” operation, with false negative readings unlikely. Almost any error in performing the test will indicate the presence of wet fuel. If the sample indicates the presence of excessive water, it is always a good practice to repeat the test on a second sample.



CONTACT INFORMATION

Fischer-Robertson, Inc.
3890 Symmes Road
Hamilton, OH 45015
ph 513-860-3445 fx 513-860-4744
www.fischer-robertson.com

BENEFITS

- **Easy to Use** – Automatically controls the sample size. Simple evaluation by color comparison.
- **Shelf Life** – One year shelf life. Refer to date on box.
- **Responds Consistently** – Responds consistently in a wide variety of aviation jet fuels.
- **Carefully Controlled Quality** – Manufactured by Parker HFFD to strict quality control specifications.

APPLICATION

- Aviation Jet (Turbine) Fuels (Not Recommended in Category M Fuels)
- Not for use with Avgas or Diesel Fuel

ORDERING INFORMATION

MODEL NO.	QTY OF TEST TUBES	
HK600@	600	(6 ea. HK100)
HK600-15	600	(6 ea. HK100-15 15 ppm sensitivity)
HK100@	100	
HK100-15	100	(15 ppm sensitivity)
HK25	25	
HK25-15	25	(15 ppm sensitivity)
HK3	3	
HK3-15	3	(15 ppm sensitivity)

Each model above comes complete with:
 sample tubes
 wide mouth glass sample jar(s)
 needle holder assembly
 instruction card
 color indicator comparison card




**Push tube down into
 needle holder in sample.**



**After tube fills, shake for
 15 seconds. Set upright to
 allow powder to settle.**



**Sample bottle must be
 clean.**



**Check powder color at
 two minutes.**



**Take sample
 DOWNSTREAM of vessel.**



**If color is the same or
 darker than FAIL, more
 than 30* ppm of free water
 is present.**

***(15 ppm of free water in HKxxx-15
 tubes.)**



Fischer-Robertson, Inc.
 3890 Symmes Road
 Hamilton, OH 45015
 ph 513-860-3445 fx 513-860-4744
www.fischer-robertson.com